
CAMSHAFT OIL CONTROL VALVE (EXHAUST SIDE BANK 1)
CAMSHAFT OIL CONTROL VALVE (INTAKE SIDE BANK 1)
FUEL INJECTOR
THROTTLE BODY
COLD START INJECTOR
INTAKE AIR CONTROL VALVE
INJECTOR DRIVER (EDU)
CAMSHAFT OIL CONTROL VALVE (EXHAUST SIDE BANK 2)
CAMSHAFT OIL CONTROL VALVE (INTAKE SIDE BANK 2)
CRANKSHAFT POSITION SENSOR


VVT SENSOR (EXHAUST SIDE BANK 1)
VVT SENSOR (INTAKE SIDE BANK 1)
FUEL PUMP (HIGH PRESSURE SIDE)
KNOCK SENSOR
VVT SENSOR (INTAKE SIDE BANK 2)
SCV POSITION SENSOR
VVT SENSOR (EXHAUST SIDE BANK 2)
FUEL PRESSURE SENSOR
IGNITION COIL WITH IGNITER
ENGINE COOLANT TEMPERATURE SENSOR
KNOCK SENSOR
DC MOTOR FOR SCV

Y